

DaPlus Dry Erase Film Application Find at www.ahutton.com
The DaPlus has a strong Pressure Sensitive Adhesive under the clear Release film

Installation Instructions:

Film Wall can be applied to various types of surfaces using a wet application method. Before applying the product, you must make sure that the surface, which the material will be applied to, is prepared properly.

Surface Preparation:

- First wash the surface that the material will be applied to with an ammonia solution or alcohol; rinse, and allow drying before installation.
- Fill any cracks, gouges, or nicks with an automotive body filler.
- After the area has been filled, sand smooth. We recommend sealing with an acrylic based sealant for absorptive surfaces.

Film Preparation:

- Film should be allowed to acclimate to room temperature for easy handling. It is recommended that room temperature be above 50°F when working with film.
- Precut the film to the size you require, leaving a few extra inches for trimming the material.
- When handling, be careful not to crease or bend the material.

Application of dry erase film:

To separate film from liner you may need to use two pieces of scotch tape!!

- Tools: squeegee, sharp knife, spray bottle, water, and dish detergent.
- Squeegee to be of rubber type so it does not scratch surface.
- First prepare surface and film as described above.
- Draw both a vertical plumb line and a horizontal level line with a pencil to use as a reference line to align the film. (Note: When covering a large area, two installers are recommended.)
- Wet surface that film will be applied to with soapy water solution. (Soapy water solution consists of a ½ cap of dish detergent to 2 gallons of water.)
- Peel about 12” of the release liner back, and spray both sides of the film.
- Position the edge of the film on the horizontal and plumb lines.
- Use the squeegee in a downward and outward motion to remove all air and water pockets and to obtain a good adhesion.
- Continue to pull back the film, and apply water to both sides of the film; continue to use the squeegee to smooth out the surface and to remove the water.
- Trim the excess material along the edges.
- Wipe down the surface with clean water, and dry with a towel.
- Allow the material to set for a couple hours before using. If you can, it is best to let the material sit overnight before using.

Care before using writing surface:

Clean the surface completely with a non-abrasive cleaner, like a glass cleaner, and a soft cloth. Once cleaned, wipe with a damp rag, and dry with a soft cloth. The purpose of this is to ensure that there is no cleaning residue left on the writing surface.

Disclaimers: This product is not designed to be removable, it probably will pull away paint from the original surface, it is designed to be permanent.