

WALL MOUNTING THE OHIO ALUMINUM FRAME

1. Mount 4 L-Brackets on wall with bottom clips at end of slot.
2. Place board and mark location of 4 holes for side of frame. Use $\frac{3}{32}$ " drill and mount using #6 phillips head screws supplied with brackets.

