


## TACKSTRIPS

### **SUGGESTED INSTALLATION INSTRUCTIONS FOR TACKSTRIPS**

Note: Complete installation hardware is included with each unit. If wall construction prevents the use of hardware as furnished, it is the responsibility of the customer to furnish the required fasteners.

#MR-3 TACKSTRIP  
WITH INSERT



1. Measure the required mounting height AFF and level and strike a chalkline at this point.
2. Place tackstrip on this line and be sure it is level across the line.
3. Place flat-headed suitable anchors 16" or 24" max O.C.
4. Slide insert into tackstrip.
5. Place endcaps onto tackstrips.

*Indoff*

140 WEST WYND TERRACE  
MIDDLETOWN, CT 06457  
(860) 632-2026  
FAX (860) 632-2028  
[www.ahutton.com](http://www.ahutton.com)