

THE AEF QUICKCONNECTLED 3 MINUTES INSTALLATION

- 1) Turn off power
- 2) Disconnect the line power connected to the existing ballast
- 3) Connect 3' power whip, hot (writing on wire) & neutral (dashed or no lines) to the line power
- 4) Magnetize the LED units to the fixture no need to change out lamp holders they are not used
- 5) Plug opposite end of the 3' power whip into the side of the 1st LED unit, plug jumper whips to connect other units as needed
- 6) To make an 8' unit connect two 4' units using the 2" connector whip
- 7) Turn power back on

(There is no need to remove ballast if it is not leaking or required for rebates. Simply leave in the fixture)





